



IN 1-4 normally feed both left and right mixers.

IN 1R and IN 2R feed the right mixer, if used, replacing IN 1 and IN 2.

Block Diagram of Matrix Mixer showing panel jack wiring..
Richard Brewster
May, 2007